



OWNERS MANUAL

Changing from left hand retrieve to right hand retrieve.

1. Unscrew spool-retaining knob (1).
2. Remove screw (2) in centre of shaft using a crosshead screwdriver and remove the washer (3).
3. Pull out bearing house (5).
4. Pull out one-way bearing (4) and turn over (blue material on bearing will be visible when set up for right hand wind).
5. Replace bearing house (5) and end washer (3).
6. Replace spool ensuring lug of centre shaft engages with slot on the back of spool.
7. Insert screw.
8. Enter spool retaining knob (1).



Changing spools

1. Turn spool locking (1) one and a half turn counterclockwise.
2. Remove spool by pulling gently
3. Replace spool ensuring lug of centre shaft engages with slot on the back of spool.
4. Tighten spool locking knob (1).

European service centers:

Swan Products APS Ltd
 Ostervangsvej 4
 DK-6715 Esbjerg
 Denmark
 45 (0)75 454630

Nordic-Lutra Norway AS
 Postbox 88
 N-2026 Strømmen
 Norway
 47 (0)63 846260

Guide Flyfishing Ltd
 8 The Vivars Centre, Canal Road
 Selby YO8 OBE
 England
 44 (0)1757 210160

Fly-Dressing AB
 Fanergatan 18
 S-56633 Habo
 Sweden
 45 (0)36 46095

OPM Kalastustarvike Oy
 Kisällintie 17
 04500 Kellokoski
 358 (0)9 2790460
 Finland