



OWNERS MANUAL

**ATTACK
VIR46
VIR68**

Vision Group Ltd
Niinistökatu 1
05800 Hyvinkää
Finland
358 (0)9 2797 610
service@visiongroup.fi

For service centers visit:
www.visionflyfishing.com

Changing from left hand retrieve to right hand retrieve.

1. Remove the c-clip (19).
2. Pull out the main gear assembly (18) and turn it over.
3. Put the parts back in reverse order.

Reel maintenance

Rinse the reel after saltwater use.

Keep the reel clean.

Add waterproof grease/oil to your reel's moving parts once a year.

Part list

1	Frame	17	Main shaft
2	Foot	18	Main gear assembly
3	Foot screw	19	C-clip
4	Spring washer	20	Spool
5	Drag nut	21	Spool bushing
6	Click ball	22	Spool bushing screw
7	Ball spring	23	Lock button
8	Drag knob	24	Lock spring
9	Drag knob screw	25	Spool cap
10	Slip washer	26	Spool cap screw
11	Drag gear - 1	27	Handle washer
12	Drag retainer	28	Handle knob
13	Clicker spring	29	Handle shaft
14	Sound click	30	Handle screw
15	Screw	31	Weight balance
16	Frame washer	32	Balance screw
		33	Frame epoxy

Exploded view

